



Notes:

o/ drawn using 19mm material

1/ the mouth deflector can be built using stepped strips or a single piece deflector

3/ damp main chamber as you would a bass reflex

4/ holey driver brace should firmly touch driver magnet, 30mm deep side braces dive sides into unequal trapezoids. Minium recommended.

VIKING

Half-Chili Chang – Fostex FE167e
Moose BVR Horn ov91
Sheet o -- panel placement
designed by Scott Lindgren
drawn by dld
13-january-2008